

Mitel Deskphones

Mitel 6867 Quick guide

Copyright © 2016 Mitel Networks Corporation

Table of Contents

- 1. Getting started 1
- 2. Basic call handling 2
- 3. Advanced call handling 3

1. Getting started

This quick guide will help you get started using your new Mitel 6867 deskphone together with the Business Communication Solution. We recommend using the phone's user guide for more information on handling the phone, please visit www.mitel.com.

1.1. Prerequisites


Your deskphone must be provisioned to your organization as a free seating phone, or provisioned to your account.

Table 1. Log in or log off from free seating phone

Log in:	<ol style="list-style-type: none"> 1. Enter the short (Alias) number in the field Log in number . 2. Press Done. 3. Enter PIN code. 4. Press Done. 5. Your username is displayed on the screen when the login is successful.
----------------	---

Log off:	<ol style="list-style-type: none"> 1. Press the Log off softkey. 2. Press Done.
-----------------	---

1.2. Phone overview



The Mitel 6867 consists of handset, screen, navigation/select key, numpad, option keys, line keys (L-keys) and softkeys (T-keys and B-keys).

1.3. Settings in the telephone

Table 2. Navigation


Navigation / Select keys:	
Up and down key:	Scroll in the menus and lists.
Left arrow key:	Go back.
Right arrow key:	Select the option.

Table 3. Set volume





Adjust volume during a call:	Press  during the call.
Adjust ringing volume:	Press  in idle mode.

Table 4. Silent ringing and mute

Silent ringing:	Press the left Volume key  until the column is empty.
Mute microphone during call:	Press 

2. Basic call handling

You can call a user in many ways: dialing the number, pressing the shortcut key, pressing and holding on a quick dial key, selecting the contact in your contact list or searching for the contact in the directory and then calling.

Table 5. Incoming calls





Answer:	Lift your handset or press 
Handsfree mode:	Press 
End call:	Press 
Reject call:	Press 

Table 6. Missed calls

Missed call indication:	Missed calls are indicated by the Missed Call text on the display.
Check missed calls:	<ol style="list-style-type: none"> 1. Press the Call log key. A list of types of calls is displayed. 2. Select Missed calls. 3. Press Select. A list is displayed. 4. Check the missed call. 5. Press Done to exit the call list.

Table 7. Outgoing calls

Internal calls:	Enter the number and press Dial .
External calls:	Enter the full number and press Dial .
Dial from call log (incoming calls):	<ol style="list-style-type: none"> 1. Press the Call log key. A list is displayed. 2. Select type of calls from the list. 3. Select the contact to call. 4. Press Select. The contact is dialed.
Dial by softkey:	Press the softkey that is assigned to a number you want to dial.
Dial by speed dial key:	Press and hold the keypad key (1-9). The number associated with the key is called.

Table 8. Transfer calls

Attended transfer:	<ol style="list-style-type: none"> 1. During your call, press the Xfer softkey. 2. Type the number to the 3rd party and press Xfer. 3. Transfer the call by pressing the Xfer softkey.
Blind transfer:	<ol style="list-style-type: none"> 1. During your call, press the Xfer softkey.

	2. Type the number to the 3rd party and press Dial .
--	---

Table 9. Holding and parking calls



Holding a call:	Press  . This will put the call on hold and play on-hold music, if that is configured.
Resume a held call:	Press  again.
Parking a call:	Press the Park softkey to park the ongoing call.
Pick up a parked call:	Press the softkey configured with Pickup .

Table 10. Conference

Conference	<ol style="list-style-type: none"> When a call is established with one party, press Conf and enter the number to third party. Press Dial. The other party is put on hold. After answer from third party, press Conf to start the conference.
-------------------	--

Table 11. Presence

Select presence:	<ol style="list-style-type: none"> Press the Presence softkey. The Presence menu is displayed. Select your preferred presence, and press Select. The option will be highlighted.
Presence shortcut:	Press the Presence shortcut to change back to the selected shortcut option, for example Office.

The presence states listed in the menu are configured by the system administrator. If a desired presence state is not listed, contact your administrator to have it added.

Table 12. Recording

Record a call:	During a call press the Recording softkey.
-----------------------	---

Table 13. Get my active call

A call is ongoing:	<ol style="list-style-type: none"> A call is ongoing on a device that belongs to you, for example a mobile phone or the soft-phone. Press *6* to pick up the call from the other device that belongs to you.
---------------------------	---

Table 14. Common Call Pickup

A group call is ongoing:	Press *5* to pickup any alerted group members calls. (Enabled by System Administrator).
---------------------------------	--



Note

Function codes for SIP phones can be configured as function key "Phone Number".

3. Advanced call handling


Table 15. Extensions

Answer a call to an extension:	<ol style="list-style-type: none"> The lamp at the Extension softkey is flashing. Press the Extension softkey to answer the call.
Call an extension:	Press the Extension softkey to call.
Answer a call monitored extension during a call:	<ol style="list-style-type: none"> Park the ongoing call by pressing the Park softkey. Answer the monitored call, press the alerted Extension softkey.

Other extensions can be monitored from softkeys on your telephone. The monitoring keys are called **Extension**. When the monitored extension is busy in a call the lamp next to the softkey is lit in red. If the extension is free the lamp is green.

Table 16. Intercom

Initiate an intercom call:	
-----------------------------------	--

	Press the Intercom softkey; the call is connected automatically.
Answer an Intercom call:	<ol style="list-style-type: none"> 1. An intercom is answered automatically. 2. You hear the other party in the speaker, but other party cannot hear you and the Mute key,  is lit. 3. You can press the mute key to let the other party hear you.

The system administrator can initiate an intercom connection on a softkey on your phone. When you press the key, a call is set up towards a predefined party and it is answered automatically.

Table 17. User voicemail

Call voicemail system:	Press the Voicemail softkey.
Listen to received messages:	<ol style="list-style-type: none"> 1. The message waiting lamp is slowly blinking and the number of messages is displayed, when there are pending messages. 2. Press the Voicemail softkey.

Table 18. Group Voicemail

Call voicemail system:	Press the Group voice inbox softkey.
Listen to received messages:	<ol style="list-style-type: none"> 1. The message waiting lamp is slowly blinking and the number of messages is displayed, when there are pending messages. 2. Press the Group inbox softkey.



Note

The system administrator can initiate a **Group Inbox** keys on your phone. Each **Group Inbox** key monitors one **Group inbox** function number. You may only monitor groups where the main user (line 1) is member. In the voice mail call, messages may be handled using keys (DTMF) described in the User Portal Inbox menu.

Table 19. Directories (Contacts)

Search for a contact:	<ol style="list-style-type: none"> 1. Press the Directory search softkey. The Directory search is displayed. 2. Enter your search information, and press Done. A list is displayed. 3. Select a contact and press Select.
Favorites:	Press the softkey configured with Favorites to bring up your personal contact list.